

DU.CNI - DU.CZS

Foundation box laying

Dig the hole according to instructions shown in Fig. 3 providing a water drain and a cable conduit in one of the special holes (Fig. 1).

Fold the two clamps Z at 45° as per Fig. 2.

Cast the casing well flat in concrete and check its horizontal position with a level.

Make sure that the cover R be inserted (Fig. 1).

**N.B.: Fig. 4 shows the maximum opening in the various positions of the casing (standard or inside).
For greater openings use the accessory DU.IT180N.**



Call our Expert Sales Team for more information.

Safety cap.

Cover fixing.

Cable hole..

Make sure that the A axis be perfectly at right angle.

