

First Fence® EchoReflect

LOOSE PANEL KIT

Height	Fixing Quantity (Bolts, Timber Only)	Fixing Quantity (Nails, For Both)
1.8m	6	220
2.0m	8	250
2.4m	8	250
2.5m	8	250
2.7m	10	310
3.0m	10	310
3.5m	12	380
4.0m	14	420
4.2m	14	420
5.0m	18	550

When fixing to timber: Rails bolt to the front of the post with M10 x 150 coach screws.

When fixing to steel: Rails attach to the steel flange with M10 x 70 coach bolts.

PRE-FABRICATED PANEL

Fixing Quantity (Bolts, Timber Only)	Fixing Quantity (Nails for capping)	Fixing Quantity (Wedges for steel only)
6	10	2
8	10	2
8	10	2
8	10	2
10	10	2
10	10	2
12	10	2
14	10	2
14	10	2
18	10	4

When fixing to timber: Use M10 x 150 coach screws

When fixing to steel: M10 x 70 coach bolts through the flange. Use 2 timber wedges per bay (except for the 5.0m panel).